

<b>ODOMETER READING SERVICE OPERATIONS - TOURING MODELS</b> (see chart code below)	1	2	5	7	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	C
	0	5	0	5	0	2	5	7	0	2	5	7	0	2	5	7	0	2	5	7	0	0
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
																						E
Change engine oil & filter	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	
Inspect air cleaner, service as required.	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Change primary chaincase lube and clean drain plug	R		R		R		R		R		R		R		R		R		R		R	
Inspect drive belt - adjust when necessary	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Inspect primary chain tension - adjust when necessary	I		I		I		I		I		I		I		I		I		I		I	
Check clutch freeplay - adjust when necessary	XL		XL		XL		XL		XL		XL		XL		XL		XL		XL		XL	
Change transmission lube and clean drain plug	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	
Inspect brake pad linings and discs for wear	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Check brake fluid reservoir levels and condition	I		I		I		I		I		I		I		I		I		I		I	
Inspect oil lines and brake system for leaks	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Lubricate front brake hand lever, throttle control cables, clutch control cables (and hand lever), and rear brake pedal bushing (if applicable)	IL		IL		IL		IL		IL		IL		IL		IL		IL		IL		IL	
Lubricate jiffy stand	L		L		L		L		L		L		L		L		L		L		L	
Steering head bearings / swing-by	I		L		IL		L		IL		L		IL		L		IL		L		D	
Check, adjust operation of enricher, (throttle control, IL every 5K & at 1 <sup>st</sup> service)	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Inspect fuel valve, lines and fittings for leaks	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Clean fuel tank filter screen, carb. @ 20K, EFI @ 25K replace									X								X					
Check operation of all electrical equipment and switches	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Check cruise control disengage switch and components	I		I		I		I		I		I		I		I		I		I		I	
Check battery and clean connections.	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Change spark plugs	I		I		R		I		R		I		R		I		R		I		R	
Check tire pressure and inspect tread	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
Check wheel spoke tightness	I		I		I		I		I		I		I		I		I		I		I	
Change front fork oil									X								X					
Check air suspension, pressure, operation & leakage	I		I		I		I		I		I		I		I		I		I		I	
Check stabilizer links and engine mounts.					I				I				I				I			I		
Check tightness of all critical fasteners: hand controls, brake system, axle nuts, front fork components, riser and handle bar fasteners.	T				T				T				T				T			T		
Inspect windshield bushings, (if applicable)					I				I				I				I			I		
Lubricate hinges, latches - fuel door, tou-r-pak, saddlebags	L		L		L		L		L		L		L		L		L		L		L	
Check engine idle speed.	I		I		I		I		I		I		I		I		I		I		I	
Road Test	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
<b>Chart Codes:</b>																						
I = Inspect, & if necessary correct, clean or replace						R = Replace or change						A = Adjust						D = Disassemble (lube & inspect)				
L = Lubricate with specified lubricant						T = Tighten to proper torque						X = Perform										

Vin# \_\_\_\_\_ Make: \_\_\_\_\_ Year: \_\_\_\_\_

Date: \_\_\_\_\_ Actual Mileage: \_\_\_\_\_ Performed By: \_\_\_\_\_